AMC X SERIES Default Settings

COMPATABLE MODELS

X412	AMC X412 Alarm Panel - FW3.78

1. USERS

<USER CODE LENGTH> 4
<TECHNICIAN CODE> (**DEFAULT 0000**)
<MASTER CODE (USER 1)> (**DEFAULT 1111**)

2. ZONES

- **ZONE MESSAGES**
  ZONE 1 TO ZONE 64
- **ZONE FUNCTION**
  DEFAULT ZONE PROGRAMMING
  (Default EOL Value: 2K2 with 1K Tamper)
  ZONE 1 - Entry Exit (E)
  ZONE 2 - Follow (P)
  ZONE 3 - Follow (P)
  ZONE 4 - Follow (P)

3. OUTPUTS

- **OUTPUTMESSAGES**
  OUTPUT1 - OUTPUT 1
  OUTPUT 2 - EXTERNAL SIREN
  OUTPUT 3 - STROBE
  OUTPUT 4 - INTERNAL SIREN
- **OUTPUT FUNCTION**
  OUTPUT 1 - MULTIFUNCTION, PULSE 5 SEC, NORMAL
  OUTPUT 2 - ALARM, 4 MIN, AUTO RESET
  OUTPUT 3 - SIREN MEMORY, AUTO RESET
  OUTPUT 4 - INTERNAL SIREN, 4 MIN, AUTO RESET

4. PERIPHERALS

- **EXPANSION PERIPHERALS -** ALL DISBALED
  KEYPADS - KEYPAD 1 ENABLED

5. OTHER PARAMETERS

- **TAMPER AP** - OFF
  QUICK ARMING - (GROUP 1, AREA 1)
  SPEAKEPHONE - ON
  SIREN TO KEYPAD - ENABLED
  SIREN SQUAWK - (REMOTE, AREA 1)
  LIFE TEST
  START - 02:30AM
  INTERVAL - 1 DAY

6. AREAS

- **AREAS**
  AREA 1 - ALL ZONES
  AREA 2 - NO ZONES
  (INSTALLER SPECIFIED)
- **AREA MESSAGES**
  AREA 1- ALL AREAS
  AREA 2- STAY
- **AREA EXIT TIMES**
  AREA 1 - 60 SECONDS
  AREA 2 - 60 SECONDS

7. GROUPS

- **GROUPS**
  GROUP 1 - LINKED TO AREA 1 <ALL AREAS>
  GROUP 2 - LINKED TO AREA 2 <STAY>
- **GROUP MESSAGES**
  GROUP 1 - ALL AREAS
  GROUP 2 - STAY

8. CONTACT ID

- ALL EVENTS ENABLED BY DEFAULT

9. ARMING LOCK

- ALL OPTIONS DISABLED

10. PSTN

- PSTN DISABLED

11. NETWORK SETUP

- **CLOUDSERVICE** - ENABLED
  CLOUD ACCOUNT
  (USER ID - 0000)
  (PASSWORD - 777777)
  LAN PARAMETERS - DHCP ENABLED
  APP NOTIFICATIONS - ALL ENABLED

12. PRIORITY CARRIERS

- **PRIORITY 01** - LAN
  PRIORITY 02 - MOBILE DATA
  PRIORITY 03 - PSTN
  PRIORITY 04 - OFF