

COMPATABLE MODELS

X824	AMC X824 Alarm Panel - FW3.78
X864	AMC X864 Alarm Panel - FW3.78

1. USERS

<USER CODE LENGTH> 4
 <TECHNICIAN CODE> (DEFAULT 0000)
 <MASTER CODE (USER 1)> (DEFAULT 1111)

2. ZONES

- **ZONE MESSAGES**
ZONE 1 TO ZONE 64
- **ZONE FUNCTION**
DEFAULT ZONE PROGRAMMING
(Default EOL Value: 2K2 with 1K Tamper)
ZONE 1 - Entry Exit (E)
ZONE 2 - Follow (P)
ZONE 3 - Follow (P)
ZONE 4 - Follow (P)
ZONE 5 - Instant (A)
ZONE 6 - Instant (A)
ZONE 7 - Instant (A)
ZONE 8 - Silent Duress 24hr

3. OUTPUTS

- **OUTPUT MESSAGES**
OUTPUT 1 - OUTPUT 1
OUTPUT 2 - EXTERNAL SIREN
OUTPUT 3 - STROBE
OUTPUT 4 - INTERNAL SIREN
- **OUTPUT FUNCTION**
OUTPUT 1 - MULTIFUNCTION, PULSE
5 SEC, NORMAL
OUTPUT 2 - ALARM, 4 MIN, AUTO
RESET
OUTPUT 3 - SIREN MEMORY, AUTO
RESET
OUTPUT 4 - INTERNAL SIREN, 4 MIN,
AUTO RESET

4. PERIPHERALS

- **EXPANSION PERIPHERALS** - ALL DISBALED
KEYPADS - KEYPAD 1 ENABLED

5. OTHER PARAMETERS

- **TAMPER AP** - OFF
QUICK ARMING - (GROUP 1, AREA 1)
SPEAKEPHONE - ON
SIREN TO KEYPAD - ENABLED
SIREN SQUAWK - (REMOTE, AREA 1)
LIFE TEST
 START - 02:30AM
 INTERVAL - 1 DAY

6. AREAS

- **AREAS**
AREA 1 - ALL ZONES
AREA 2 - NO ZONES
 (INSTALLER SPECIFIED)
- **AREA MESSAGES**
AREA 1 - ALL AREAS
AREA 2 - STAY
- **AREA EXIT TIMES**
AREA 1 - 60 SECONDS
AREA 2 - 60 SECONDS

7. GROUPS

- **GROUPS**
GROUP 1 - LINKED TO AREA 1 <ALL AREAS>
GROUP 2 - LINKED TO AREA 2 <STAY>
- **GROUP MESSAGES**
GROUP 1 - ALL AREAS
GROUP 2 - STAY

8. CONTACT ID

- ALL EVENTS ENABLED BY
DEFAULT

9. ARMING LOCK

- ALL OPTIONS DISABLED

10. PSTN

- PSTN DISABLED

11. NETWORK SETUP

- **CLOUDSERVICE** - ENABLED
CLOUD ACCOUNT
 (USER ID - 0000)
 (PASSWORD - 777777)
LAN PARAMETERS - DHCP ENABLED
APP NOTIFICATIONS - ALL ENABLED

12. PRIORITY CARRIERS

- **PRIORITY 01** - LAN
PRIORITY 02 - MOBILE DATA
PRIORITY 03 - PSTN
PRIORITY 04 - OFF