



## AMC K4 PANEL TO AMISIDE140 SIREN


**K4**



----- Connect for reporting system status, or usable for the flasher separate reporting (see Siren manual)

## AMC K8 - K8PLUS PANEL TO AMISIDE140 SIREN




### K8 - K8PLUS



----- Connect for reporting system status, or usable for the flasher separate reporting (see Siren manual)

## AMC X SERIES PANEL TO AMISIDE140 SIREN

### X PANEL BOARD



----- Connect for reporting system status, or usable for the flasher separate reporting (see Siren manual)